

Category: Hair Care

CM1-090 Color Protect Conditioner

<i>Ingredient</i>	<i>INCI</i>	<i>Supplier</i>	<i>W/W%</i>
<i>PHASE A</i>			
DI Water	Water	In House	83.500
<i>PHASE B</i>			
Nequat DBS	Stearyl Alcohol (& Stearamidopropyl Ethldimonium Ethosulfate (& Dimethyl Lauramine (& Dilinoleic Acid	ALZO	6.000
Cetyl Alcohol	Cetyl Alcohol	ALZO	4.000
Dermol DISM	Diisostearyl Malate	ALZO	2.000
Dermol GRC	Glyceryl Ricinoleate	ALZO	2.000
Polyderm PPI-SA	Di-PEG-2 Soyamine/IPDI Copolymer	ALZO	1.000
Polyderm PPI-SA15	PEG-15 Soyamine/IPDI Copolymer	ALZO	1.000
<i>PHASE C</i>			
TroyCare FE10	Iodopropynyl butylcarbamate/Phenoxyethanol	Troy	0.500
Total			100

Manufacturing Procedure:

1. In the primary vessel Heat and mix phase A to 80°C
2. In a side Vessel heat and mix Phase B to 80°C
3. Under high shear mixing combine Phase B into Phase A
4. Cool Batch to below 40°C Add Phase C and drop batch

All information contained herein is intended primarily to demonstrate the utility of **ALZO** products. Suggestions for uses or applications are only opinions. The user is responsible for determining the suitability of these products for their own particular purpose. We assume no liability in the presentation of this data, nor should this information be constructed as granting license to practice any methods or compositions of matter covered by U.S. or foreign patents.