

Category: NuPlastic Long Wear Color Cosmetics

CR2-237: NuPlastic Eye Shadow

<i>Ingredient</i>	<i>INCI</i>	<i>Supplier</i>	<i>W/W%</i>
Phase A			
NuPlastic Silk-E ID LSA-10	Isododecane and Polysilicone (23)	Alzo International	50.0
Dermol 99	Isononyl Isononanoate	Alzo International	9.5
Simulgel EG	Sodium Acrylate/Sodium Acryloyl-dimethylaurate Copolymer and Isohexadecane and Polysorbate 80	Seppic	0.3
Polyderm PPI PE PA ED	Polyurethane-58	Alzo International	30.0
Phase B			
Mica	Mica	Kobo	2.0
Cloisonne Sparkle Gold	Mica and Titanium Dioxide and Iron Oxides	BASF	4.0
Syncrystal Silk Silver	synthetic fluorphlogopite (and) titanium dioxide (and) tin oxide	Eckart	4.0
Phase C (Preservative)			
Microcare MBG	Polyhexamethylenebiguanide	Thor	0.2
Total			100

Procedure:

- 1) Combine Phase A and mix with an overhead mixer
- 2) Add Phase B to Phase A and homogenize
- 3) Add preservative and mix until homogeneous